




CONEXÕES ACESSÓRIAS

ADAPTADORES DE MONTAGEM
LATÃO NIQUELADO

Adaptadores De Latão

Espigão



Modelo		
Código	Tubo Ø	Rosca
PHTM 07-01	1/4	1/8
PHTM 07-02	1/4	1/4
PHTM 08-01	5/16	1/8
PHTM 08-02	5/16	1/4
PHTM 10-02	3/8	1/4
PHTM 10-03	3/8	3/8
PHTM 10-04	3/8	1/2
PHTM 12-02	1/2	1/4
PHTM 12-03	1/2	3/8
PHTM 12-04	1/2	1/2

Cotovelo “M-F”



Modelo	
Código	Rosca
PEFL 01	1/8
PEFL 02	1/4
PEFL 03	3/8
PEFL 04	1/2

Cotovelo “F x F”




Modelo	
Código	Rosca
PFL G01	1/8
PFL G02	1/4
PFL G03	3/8
PFL G04	1/2

“T” Femêa




Modelo	
Código	Rosca
PFT G01	1/8
PFT G02	1/4
PFT G03	3/8
PFT G04	1/2

Luva




Modelo		
Código	Rosca	
	A	B
PSF 01-01	1/8	1/8
PSF 02-01	1/4	1/8
PSF 02-02	1/4	1/4
PSF 03-02	3/8	1/4
PSF 03-03	3/8	3/8
PSF 04-03	1/2	3/8
PSF 04-04	1/2	1/2

Niple



Modelo		
Código	Rosca	
	A	B
PSM 01-01	1/8	1/8
PSM 02-01	1/4	1/8
PSM 02-02	1/4	1/4
PSM 03-02	3/8	1/4
PSM 03-03	3/8	3/8
PSM 04-02	1/2	1/4
PSM 04-03	1/2	3/8
PSM 04-04	1/2	1/2
PSM 06-04	3/4	1/2
PSM 06-06	3/4	3/4
PSM 08-08	1	1

Adaptador “M x F”



Modelo		
Código	Rosca	
	A	B
PSMF 02-01	1/4	1/8
PSMF 03-02	3/8	1/4
PSMF 04-02	1/2	1/4
PSMF 04-03	1/2	3/8

Bucha de Redução “M x F”



Modelo		
Código	Rosca	
	A	B
PRMF 01-M5	M5	1/8
PRMF 02-01	1/8	1/4
PRMF 03-01	1/8	3/8
PRMF 03-02	1/4	3/8
PRMF 04-01	1/8	1/2
PRMF 04-02	1/4	1/2
PRMF 04-03	3/8	1/2
PRMF 06-04	1/2	3/4
PRMF 08-04	1/2	1
PRMF 08-06	3/4	1

Tampão Rosca



Modelo	
Código	Rosca
POH 01	1/8
POH 02	1/4
POH 03	3/8
POH 04	1/2

Tampão C/ O’Ring



Modelo	
Código	Rosca
POHH G01	1/8
POHH G02	1/4
POHH G03	3/8
POHH G04	1/2

Engate Rápido

Pino Femêa



Modelo	
Código	Rosca
PF20	1/4
PF30	3/8
PF40	1/2

Pino Macho



Modelo	
Código	Rosca
PM20	1/4
PM30	3/8
PM40	1/2

Engate Fêmea



Modelo	
Código	Rosca
SF20	1/4
SF30	3/8
SF40	1/2

Engate Macho



Modelo	
Código	Rosca
SM20	1/4
SM30	3/8
SM40	1/2

Válvula Esfera

Esfera Monobloco



Modelo	
Código	Rosca
BV01	1/8
BV02	1/4
BV03	3/8
BV04	1/2
BV06	3/4
BV10	1

Mini Esfera Macho/Fêmea



Modelo	
Código	Rosca
MBVMF-01	1/8
MBVMF-02	1/4
MBVMF-03	3/8
MBVMF-04	1/2

Silenciador com Controle de fluxo



Modelo	
Código	Rosca
BESL-01	1/8
BESL-02	1/4
BESL-03	3/8
BESL-04	1/2

Silenciador faceado



Modelo	
Código	Rosca
BSLM-01	1/8
BSLM-02	1/4
BSLM-03	3/8
BSLM-04	1/2

Silenciador



Modelo	
Código	Rosca
BSL-M5	M5
BSL-01	1/8
BSL-02	1/4
BSL-03	3/8
BSL-04	1/2

Silenciador de Alumínio



Modelo	
Código	Rosca
LM-1	1/8
LM-2	1/4
LM-3	3/8
LM-4	1/2
LM-6	3/4
LM-8	1

Silenciador Plástico



Modelo	
Código	Rosca
PSU-01	1/8
PSU-02	1/4
PSU-03	3/8
PSU-04	1/2

Mola para Espiral 1/4

